



## How to Iron-on Embroidered Patches

1. Garment should be clean & freshly laundered (including new items)
2. Heat the iron to the highest setting
3. Flatten area of garment where patch will be placed
4. Place patch on garment, embroidery facing up
5. Place cloth or light towel over patch and using a slow circular motion, press firmly for 2-3 minutes. If applying patch to non-cotton items make sure that the cloth is big enough to cover the whole surface of the iron
6. Turn garment inside out, place cloth and iron the back of the patch for another 2-3 minutes
7. Let cool for at least 30 minutes. If edge of patch can be lifted, repeat step 6

Do NOT bleach.

When machine washing or tumble drying, turn the item inside out.